ADVANCED CHASSIS CONVERSION KIT FOR THE LOSI LMT

















OGRE_X LMT Conversion kit

1. Cut Losi LMT Mega Center Shafts #LOS242057 down to length. Usually this is 15 to 18mm off each end depending on your setup. Take care and test fit with full suspension cycle. If you feel you cut too much thankfully replacement plastic drive shafts(#LOS242057) are only \$11.99.

2. Install drive shafts per the TLR Tuned Losi LMT manual if you need install reference.

1. Trim Lengths:

- A. Shorter wheelbase or with less axle tilt/flat axle (more caster).
- B. Longer wheelbase or with axle tilted up/angled axle (less caster)







OGRE_X LMT Conversion kit

